



# Result Clothing Care and Size Guide

## Fabric Information

Result clothing is 100% waterproof and windproof.

Their clothing is made from a lightweight fabric that has a coated backing and is fully waterproof to at least 2000mm.

## Washing and Care Guide

PLEASE REMEMBER to refer to the care labels for each specific garment and carefully follow instructions. The way you clean your waterproofs can make the difference from them lasting a few weeks to lasting a few years.

Every time you wash any outdoor clothing it reduces its waterproof ability. If you can, try not to wash waterproofs in the washing machine. Leave them muddy and brush the mud off when it dries or use the bucket cleaning technique - see below.

Fill a bucket with cool water. DO NOT ADD ANY DETERGENT. Before washing the garment, brush off any loose mud or dirt. Close zips, velcro fastenings and flaps on jackets and trousers. Put the waterproofs into the bucket and slosh around. Two buckets may be necessary if they are particularly dirty. Hang up to dry in a position that allows air movement.

Result clothing is machine washable, however you need to refer to the care label for each individual item of clothing. Please be aware that even if you follow the care instructions carefully, washing waterproof clothing in the washing machine will reduce their waterproof lifespan. If you are washing in a machine make sure the detergent compartment of your washing machine is clean of any detergent or softener. If you run a hot wash program whilst the machine is empty, prior to washing the waterproofs, it will help clear detergent or softener residue.

**DETERGENT** - Waterproof clothing should never be washed using ordinary detergent or fabric softener. The chemicals in detergent can break down the composition of the fibres with each wash and strip the fabric of its waterproof coating.

Remember to always check the label of your garment for exact care details.

After washing the garment hang up to air dry. IF garment care instructions allow tumble dry do this on a low heat for a few minutes to restore the Teflon proofing. Make sure all waterproofs are completely dry before storing away, to avoid them becoming moldy or musty. Avoid storing in direct sunlight.

If you notice that the fabric of your jacket or trousers is absorbing rather than repelling water you may also need to re-waterproof your garment.

# Result Clothing Care and Size Guide

## Result Size Guide

Sizes vary slightly depending which item of clothing you are buying. Please check the tables below carefully.

### Children

#### Fleeces

Sizes	XXS	XS	S	M	L	XL
Age in yrs	3-4	4-6	6-8	8-10	10-12	12-14
Height cm	96-104	104-116	116-128	128-140	140-152	152-164
Chest cm	55-56	57-61	61-66	67-72	72-79	79-86

#### Pack in a Bag

Sizes	XS	S	M	L	XL
Age in yrs	3-4	5-6	7-8	9-10	11-12
Height cm	96-104	108-116	120-128	132-140	144-152
Chest cm	55-57	59-61	64-67	70-73	76-79

#### Jacket

Sizes	XXS	XS	S	M	L	XL	2XL
Age in yrs	2-3	3-4	5-6	7-8	9-10	11-12	13-14
Height cm	88-96	98-104	108-116	120-128	133-140	144-152	156-164
Chest cm	50-53	55-57	59-61	64-67	70-73	76-79	82-87

#### Trousers

Sizes	S	M	L	XL	2XL
Age in yrs	5-6	7-8	9-10	11-12	13-14
Height cm	108-116	120-128	133-140	144-152	156-164
Waist cm	56	58	64	69	74

### Adults

#### Ladies Jackets

Sizes	XS	S	M	L	XL	2XL
UK	8	10	12	14	16	18
Chest cm	91	96	101	106	111	116

#### Mens Jackets

Sizes	S	M	L	XL	2XL	3XL
Chest	96	104	112	117	132	135

# Result Clothing Care and Size Guide

Unisex

<b>Sizes</b>	<b>S/M</b>	<b>L/XL</b>	<b>2X/3XL</b>
<b>Chest cm</b>	117	132	
<b>Waist cm</b>	78-86	86-97	97-102
<b>Inside leg cm</b>	81	81	81

Pack in bag

<b>Size</b>	<b>S</b>	<b>M</b>	<b>L</b>	<b>XL</b>	<b>2XL</b>
<b>Chest</b>	94	104	114	125	135
<b>Waist</b>	76-81	81-86	86-91	91-97	97-102
<b>Inside leg</b>	74	76	79	80	81

\*Please note sizes are approximate and for guidance only